




***Stocks*AG**

Maxi Jet 2 and 4 i-CON

ORIGINAL OPERATING MANUAL & PARTS LIST



Read carefully before installation and operation

This document must not be copied duplicated or distributed without prior consent.
All intellectual property and patent rights apply.



Stocks Ag Limited.

Cromwell Road, Wisbech, Cambridgeshire, PE14 0SD, UK
01945 464909 sales@stocks-ag.co.uk www.stocks-ag.co.uk



| Section | Page |
|--|-----------|
| E.C. DECLARATION OF CONFORMITY | 5 |
| UKCA. DECLARATION OF CONFORMITY | 6 |
| 1.0 General Information | 7 |
| 1.1 Technical Data | 7 |
| 1.2 Intended Use | 7 |
| 1.3 Unintended Use | 7 |
| 1.4 Machine Identification | 8 |
| 1.5 Warranty | 8 |
| 2.0 Safety | 9 |
| 2.1 Safety Warning Decals | 10 |
| 3.0 Emergency Stop Instructions | 11 |
| 4.0 Storage | 11 |
| 5.0 PVC Waterproof Covers | 11 |
| 6.0 Disposal | 11 |
| 7.0 General Maintenance | 12 |
| 7.1 Before Use | 12 |
| 7.2 Daily Checks | 12 |
| 7.3 After Each Use | 12 |
| 8.0 Installation Guide | 13 |
| 8.1 Base Plate | 13 |
| 8.2 Spreader Plates | 14 |
| 8.3 Riser Pipes and Distribution Head | 14 |
| 8.4 Spreader Plates Set Up | 14 |
| 8.5 C Section Rail | 16 |
| 8.6 Feed Hose | 16 |
| 9.0 Maxi Jet Configuration | 17 |
| 9.1 Distribution Heads | 18 |
| 10.0 Machine Components | 19 |
| 10.1 Feed Motor | 19 |
| 10.2 Hopper Agitator | 19 |
| 10.3 Hydraulic Fan Unit | 19 |
| 10.4 Main Power Cable | 20 |
| 10.5 Instrument Lead | 20 |

| Section | | Page |
|-------------|--------------------------------------|-----------|
| 10.6 | Spring Finger Switch | 20 |
| 10.7 | Junction Box | 21 |
| 10.8 | i-CON Instrument | 21 |
| 10.9 | Hopper Level Sensor | 21 |
| 10.10 | Feed Rollers | 21 |
| 11.0 | Inspection | 22 |
| 11.1 | Fan Inspection | 22 |
| 11.2 | Feed Block Assembly Inspection | 22 |
| 11.3 | Agitator Shaft Inspection | 22 |
| 12.0 | Hopper Emptying Procedure | 23 |
| 13.0 | Clearing A Feed Hose Blockage | 23 |
| 14.0 | Checking The Feed Motor | 23 |
| 15.0 | i-CON Control System | 24 |
| 15.1 | i-CON Overview | 24 |
| 15.2 | Wiring Diagram | 24 |
| 15.3 | i-CON Instrument Functions | 25 |
| 15.4 | Precision Farming Software Access | 25 |
| 16.0 | i-CON Calibration | 26 |
| 16.1 | At The Junction Box | 26 |
| 16.2 | At The i-CON Cab Instrument | 26 |
| 16.3 | Manual Calibration | 27 |
| 16.4 | GPS Speed | 27 |
| 16.5 | Common Calibration Mistakes | 27 |
| 16.6 | Ready For Work | 27 |
| 17.0 | Feed Block Assembly Guide | 28 |
| 17.1 | Feed Roller Configuration | 28 |
| 17.2 | Small Seed/Granular Rollers | 29 |
| 18.0 | Hopper Baffle Plate | 29 |
| 19.0 | Hydraulic Fan Specification | 30 |
| 19.1 | Hydraulic Fan - Motor | 30 |
| 19.2 | Hydraulic Fan - Safety | 31 |
| 19.3 | Hydraulic Fan - Fitting Position | 31 |
| 19.4 | Hydraulic Fan - Speed Setting | 32 |
| 19.5 | Hydraulic Fan - Speed Guide | 32 |

| Section | | Page |
|-------------|--|-----------|
| 19.6 | Hydraulic Fan - Speed Display | 33 |
| 19.7 | Hydraulic Fan - Speed Sensor | 33 |
| 19.8 | Hydraulic Fan - Mounting | 34 |
| 20.0 | Maxi Jet Parts - Control System | 35 |
| 20.1 | Maxi Jet Part Drawing | 36 |
| 20.2 | Maxi Jet Parts List | 37 |
| 21.0 | Feed Rollers | 40 |
| 21.1 | High Capacity 59mm Feed Roller Kit Parts | 40 |
| 21.2 | Standard Feed Roller Kits Parts - Full Set | 41 |
| 21.3 | Standard Feed Roller Kits Parts - 4 segments inc spacers | 42 |
| 21.4 | Standard Feed Roller Kits Parts - 2 segments inc spacers | 43 |
| 21.5 | Feed Roller Kits Parts List - Small Seed Roller Kit | 44 |
| 22.0 | Hydraulic Fan - Parts (Diagram) | 45 |
| 22.1 | Hydraulic Fan - Parts List | 45 |



E.C. DECLARATION OF CONFORMITY

Machine Type: Mounted Agricultural Implement - Pellet and Seed application broadcasters

| | | |
|------------------|--------------|---------------------------|
| Model(s): | Fan Jet Pro | All Variants and Versions |
| | Fan Jet Plus | All Variants and Versions |
| | Fan Jet Mini | All Variants and Versions |
| | Fan Jet Duo | All Variants and Versions |
| | Maxi Jet | All Variants and Versions |
| | Turbo Jet | All Variants and Versions |
| | Rotor Meter | All Variants and Versions |
| | Rotor Jet | All Variants and Versions |
| | Micro Meter | All Variants and Versions |
| | Maxi Meter | All Variants and Versions |

Serial No.

Manufacturer: Stocks Ag Ltd
Cromwell Road
Wisbech
Cambridgeshire PE14 0SD
United Kingdom

This is to declare that the above machine conforms to the relevant Essential Health and Safety Requirements of the Machinery Directive 2006/42/EC, implemented in the United Kingdom by Statutory Instrument 2008 No. 1597 – The Supply of Machinery (Safety) Regulations 2008 as amended.

The following standards have been applied in the design and construction of this machine:

| | | |
|-------------------|------|--|
| BS EN ISO 12100: | 2010 | Safety of machinery – General principles for design – Risk assessment and Risk reduction. |
| BS EN ISO 4254-1: | 2015 | Agricultural machinery – Safety - General requirements. |
| BS EN ISO 4254-8: | 2018 | Agricultural machinery. Safety - Solid fertiliser distributors. |
| BS EN ISO 13854: | 2019 | Safety of machinery – Minimum gaps to avoid crushing of parts of the human body. |
| BS EN ISO 13857: | 2019 | Safety of machinery – Safety distances to prevent hazard zones being reached by the upper and lower limbs. |

The manufacturer stated above holds the technical file for this machine.

Signed on behalf of Stocks Ag Ltd

Name:  J Woolway

Date: 06th August 2020

Position: Managing Director

t. +44 (0) 1945 464909 f. +44 (0) 1945 464985 e. sales@stocks-ag.co.uk



**UKCA. DECLARATION OF CONFORMITY**

Machine Type: Mounted Agricultural Implement - Pellet and Seed application broadcasters

| | | |
|-----------|--------------|---------------------------|
| Model(s): | Fan Jet Pro | All Variants and Versions |
| | Fan Jet Plus | All Variants and Versions |
| | Fan Jet Mini | All Variants and Versions |
| | Fan Jet Duo | All Variants and Versions |
| | Maxi Jet | All Variants and Versions |
| | Turbo Jet | All Variants and Versions |
| | Rotor Meter | All Variants and Versions |
| | Rotor Jet | All Variants and Versions |
| | Micro Meter | All Variants and Versions |
| | Maxi Meter | All Variants and Versions |

Serial No.

Manufacturer: Stocks Ag Ltd
Cromwell Road
Wisbech
Cambridgeshire PE14 0SD
United Kingdom

This is to declare that the above machine conforms to the relevant Essential Health and Safety Requirements of the Machinery Directive 2006/42/EC, implemented in the United Kingdom by Statutory Instrument 2008 No. 1597 – The Supply of Machinery (Safety) Regulations 2008 as amended.

The following standards have been applied in the design and construction of this machine:

| | | |
|-------------------|------|--|
| BS EN ISO 12100: | 2010 | Safety of machinery – General principles for design – Risk assessment and Risk reduction. |
| BS EN ISO 4254-1: | 2015 | Agricultural machinery – Safety - General requirements. |
| BS EN ISO 4254-8: | 2018 | Agricultural machinery. Safety - Solid fertiliser distributors |
| BS EN ISO 13854: | 2019 | Safety of machinery – Minimum gaps to avoid crushing of parts of the human body. |
| BS EN ISO 13857: | 2019 | Safety of machinery – Safety distances to prevent hazard zones being reached by the upper and lower limbs. |

The manufacturer stated above holds the technical file for this machine.

Signed on behalf of Stocks Ag Ltd

Name:  J Woolway

Date: 01st December 2020

Position: Managing Director

t. +44 (0) 1945 464909 f. +44 (0) 1945 464985 e. sales@stocks-ag.co.uk



1.0 General Information

Congratulations on your Maxi Jet purchase.

Please check the machine for any transport damage upon receipt and advise your supplier of any problems immediately. Late claims regarding any damage may be rejected.

Specifications, descriptions and illustrations in this manual are accurate at the time of publication but may be subject to change. This manual is correct at the time of printing but we reserve the right to change and improve. This machine is designed with safety in mind. Maintenance and servicing in accordance with this manual will ensure safe operation and reliability of your machine for many years.

IMPORTANT: This Operating Manual forms part of the machine and must be readily available for the operator who must read and follow the points covered before use.

1.1 Technical Data

Model: Maxi Jet 2 i-CON, Maxi Jet 4 i-CON

Hopper capacity: 240 litre or 400 litre

240 litre machine:

Net weight: 136kg

Dimensions: (WxDxH) 65x130x109cm

Max. spreading width:

Maxi Jet 2: 8m

Maxi Jet 4: 15m

400 litre machine:

Net weight: 146kg

Dimensions: (WxDxH) 65x130x136cm

Recommended working width:

Maxi Jet 2: 8m

Maxi Jet 4: 15m

Operating voltage 12v: power requirement 30 amps, motor output 360 watt

Power consumption of the motor: 35 amps when starting, up to 30 amps during normal operation

Noise level: 90dB hydraulic fan (optional)

1.2 Intended Use

This Maxi Jet has been designed solely to apply small seed and granular products for use in the agricultural, horticulture and the amenity sector.

Any other use is considered to be non-intended and the manufacturer will not be liable for any resulting damage.

This machine should not be used in the rain or during a thunderstorm.

The manufacturer is not liable for any resulting damage if the machine is used for any other purpose than the intended use and also includes compliance with the conditions for operation, maintenance, and repairs prescribed within this instruction manual.

The applicable accident prevention regulations as well as the other generally safety-related, occupational health and road traffic regulations must also be observed.

NOTE: Do not operate this machine during adverse weather conditions.

1.3 Unintended Use

This machine is not designed to apply abrasive materials such as sand and grit or for applying salt products.

The operator alone bears the associated risk if used for non-intended use.

1.4 Machine Identification

Example Decal Only



The machine can be identified by the serial number decal mounted on the steel chassis to the left of the feed cassette.

1.5 Warranty

We provide a 12 month warranty from the date of invoice (the invoice for the machine will serve as a warranty certificate).

This warranty is applicable for cases of material or construction faults and does not include parts that are damaged by normal or excessive wear.

Warranty expires if damage is caused by external forces, operator error, modifications, jet washing or if the machine has been used for unintended use.

In the event of any problems, or before attempting any repair, please contact the company from where the machine was purchased. If the base machine or the control system are modified in any way this will void any warranty claim.

Stocks Ag cannot be held responsible for any claims or injuries to the owner or any third parties while in the operation of Stocks Ag equipment.

On no account can Stocks Ag be held liable for accidental or consequential damages (including loss on anticipated profits) for any impairment due to failure or defect of the machine.

Please see our conditions of sale for full details, a copy of which available upon request.

Please record the machine serial number here: S/N

Purchase date: Dealer

2.0 Safety

Ensure care is taken when lifting the machine. Safe lifting practice to be observed when handling as the net weight is over 25kg.



- We advise safety shoes and protective gloves are worn when handling the machine.
- Assistance will be required when lifting or lowering the machine.
- Care to be taken to avoid crushing due to the weight of the machine.
- When lifting or fitting the machine on to a parent vehicle or implement ensure work is performed on level ground or flat surface to avoid slipping, stumbling or falling.

PERSONAL PROTECTION EQUIPMENT

It is the responsibility of the operator or maintenance engineer to ensure safe handling of the machine and the appropriate personal protection equipment must be worn for the material being applied and to prevent contamination to the machine or the environment.

⚠ WARNING! Ear protection required if working in close proximity to the machine as it exceeds 80dB.

PRODUCT APPLIED

If applying slug pellets or other toxic material and the parent vehicle has a closed cab the operator must ensure the cabin is always closed and the air filter system is in good order. If fitted to a UTV vehicle ensure the stability of the parent vehicle is not affected when the machine is in use. If in doubt contact the vehicle manufacturer for more information. After working the machine ensure that any unused product is returned safely to its original packaging. Stocks Ag Ltd. does not accept any liability for the storage and use of the material being applied.

NOTE: If unsure contact your seed or product supplier for more information.

⚠ WARNING! Always observe all application standards and guidelines provided by the product manufacturer as some seed dressings and granular products may be toxic.

OPERATION AND MAINTENANCE

The machine may only be used, maintained and repaired by persons who have relevant experience or a machinery dealer who is aware of any risks involved. The applicable accident prevention regulations as well as the other generally safety related, occupational health and road traffic regulations must also be observed.

The manufacturer is not liable for any damage resulting from unauthorised modifications and the use of components and auxiliary parts. The machine must be checked regularly by the operator (before each use) for any damage, loose bolts or electrical connections, vibrations, unusual sounds, and to ensure it functions correctly.

The machine must not be operated in wet weather conditions or during thunderstorms. Observe the generally applicable safety and accident prevention regulations. Always empty the hopper of toxic materials to prevent harm to humans and animals after each use and prior to storage.

⚠ WARNING! Do not put your hands inside the hopper when the agitator motor is turning as the agitator shaft inside the hopper rotates at high speed and is sharp and dangerous.

⚠ WARNING! Always isolate the power supply if servicing or leaving the machine unattended.

2.1 Safety Warning Decals

Important: Be aware of the safety warning below which are all relevant to this machine



⚠ WARNING!

Read and understand the Operators Manual instructions before operating this machine.


Operator errors can result in serious injury.



⚠ WARNING!

Danger due to thrown or flying objects.

Always maintain a safe distance whilst the machine is in operation.



⚠ WARNING!

Risk of injury. Possible trapping point when tipping hopper.



⚠ WARNING!

Risk of injury.

Be aware the feed mechanism is powerful and can cause serious injury.



⚠ WARNING!

Keep Clear!

Maintain a safe distance from the machine when in operation.

Wear the appropriate protective personal equipment.



⚠ WARNING!

Do Not Jet Wash. This machine is not designed to withstand jet washing.

3.0 Emergency Stop Instructions

Power down the control system immediately by pressing and holding down the left-hand rubber end cap on the instrument control panel for approximately 2 seconds — then release to power off.



4.0 Storage

Disconnect the power supply by unplugging the power cable or by removing the 40amp fuse fitted in the power cable.

It is the responsibility of the operator to ensure the hopper is empty after use and cleaned thoroughly before storage.

Store in dry conditions to protect the machine and control system from moisture.

Always clean and spray electrical connectors with a moisture repellent spray when not in use for long periods.

Fit the PVC waterproof cover (if available).

Ensure feed blocks are free to turn and all electrical cables checked following periods of storage.

5.0 PVC Waterproof Covers - Optional

Heavy duty white PVC covers are available for both the 240L and 400L machines, fitted with eyelets and bungie cord for easy attachment.

240L Model: TJ240COVER 400L Model: TJ400COVER

Please contact your locals Stocks Ag dealer for more information.

6.0 Disposal

Ensure that any persons handling the machine are aware that the machine may have been used to apply toxic chemicals and so the appropriate personal protection equipment should be worn.

Ensure the hopper contents and any toxic residue have been removed and put back into a sealed container or disposed of in accordance with the manufacturers guidelines to eliminate any possible contamination of others or the environment.

Always adhere to the local disposal regulations paying particular attention to the plastics, rubber, and electrical components.

7.0 General Maintenance

⚠ WARNING! Always ensure the power supply is disconnected before any maintenance work or cleaning of the machine by unplugging the power cable or removing the 40amp fuse in the power cable.

Ensure the parent machine is stationary and parked on level ground before working on the machine.

The machine must be checked regularly by the operator for any damage, loose bolts or electrical connections, vibrations, unusual sounds, and to ensure it functions correctly.

⚠ WARNING! Protective clothing must be worn when applying or handling toxic products.

Always observe all guidelines provided by the product manufacturer with regards to handling, storage and disposal of products. Take care not to spill any product that could contaminate the machine or the environment ensuring any product removed from the machine is put back into its original container.

7.1 Before Use

1. Ensure the machine is securely mounted.
2. Check the power supply and ensure the power cable is connected directly to the vehicle battery.
3. Check the feed block is configured correctly and free running before starting work.

7.2 Daily Checks

1. Check the feed motor and agitator motors are working correctly.
2. Check the hydraulic fan and air intake meshes are clean and free from any debris.
3. Check feed hoses for any blockages and all hose clips are tight.
4. Check the spreader plates are positioned correctly.
5. Check hoses to hydraulic fan for oil leaks and signs of damage.

7.3 After Each Use

1. Empty hopper and clean the machine thoroughly.
2. Disconnect the power supply.
3. Replace the PVC waterproof cover (if applicable).
4. Store in dry conditions to protect the machine and control system from moisture.

⚠ WARNING
DO NOT JET WASH THIS MACHINE.



8.0 Installation Guide

The Maxi Jet can be used for a wide variety of seeding applications in conjunction with a wide variety of parent implements.

It is not practical to supply tailored mounting brackets for every implement on the market, and so the final attachment of the Maxi Jet to the implement is the responsibility of the supplying dealer or end user.


The position of the hopper, the spreader plate, the "C" section mounting rails will depend upon the type and design of the parent implement. Here are a few basic pointers to ensure the Maxi Jet performs correctly.

Position the Maxi Jet high enough above the implement to facilitate routing of the flexible tubes to the riser pipes, without severe bends or uphill runs. Try to route all tubes generally downhill. Do not block the air intakes to the hydraulic fans.

Ensure the wing sections do not foul the hopper or cause the riser pipes to clash. All hose runs are long enough to fold with the implement, without a restriction when in work.

Ensure you can access the hopper to fill, and are able to remove the feed block assembly and position the calibration tray underneath to calibrate or empty.


When filling, emptying or calibrating the Maxi Jet ensure you work safely. If necessary fabricate and fit a work platform and steps, complete with handrails. The hopper may face forwards or backwards– whichever offers the easiest mounting and best flexible tube run. Select a strong, rigid position and use the heavy flat base plate provided to weld or bolt to your implement as per the example below. The 2 or 4 riser pipes will need mounting across the width of the machine. The support brackets for the riser pipe will require fabricating to a design that is suitable for the particular host machine.



Above right is an example of how to mount a riser pipe. Brackets not supplied.

8.1 Base Plate

Part No. TJ422 - Dimensions and fixing hole detail



8.2 Spreader Plates

The Maxi Jet can be ordered with combinations of 12 to 64 outlets. Depending on the implement width and if you require a broadcast or band sown effect.

Plan the position of the riser pipes and spreader plates to be equal distant across the width of your implement. Aim to route all hoses smoothly and generally downhill from the hopper to the riser pipes, then from the distribution heads down to the spreader plates, avoiding severe bends and uphill runs.

8.3 Riser Pipes and Distribution Heads

The Maxi Jet has either two or four riser pipes that are connected to the base machine with 63mm hose. Each riser pipe can be supplied with a choice of distribution heads. The six outlet heads use a 32mm hose, the 8, 10, 12 and 16 outlet heads all use 25mm hose.

8.4 Spreader Plate Set Up


The Stocks Ag spreader plate was developed to allow a wider spread pattern while positioning the outlets closer to the ground.

For products such as grass seed, oil seed rape and Avadex, a spread width per outlet of 750mm is achievable from as low as 250mm above the ground (250mm to the bottom plate).

A 6m grass harrow only requires 8 evenly spaced outlets. In many circumstances reducing the need for Y piece splitters and having double the outlets.


The spreader plates have two main adjustments to set up the optimum spread pattern to suit a variety of products and machine fitments.

The main bottom plate requires bending into position. The angle of the bottom plate alters the spread width from each outlet. A common setup would be to bend from vertical to approximately 15° from parallel to the top plate (see below).




8.4 Spreader Plate Set Up – Continued

There are two adjustable tabs on the back plate of each outlet. These tabs are used to create an even arc shaped spread pattern and adjust overlaps between outlets, when required.



By bending the back plate tabs in slightly (see diagram below).



The coverage of product over the ground can be made much more even.



These recommended settings are an initial guide, set up may vary between different products and machine fitments and required further adjustment.

8.5 C Section Rail

The spreader plates themselves are mounted to the “C” section rails, these can be ordered in 2m lengths as an option. Part no. **47TJT5008**. These can be cut down to suit the implement width. The “C” section rails can be attached to the implement using the supplied straight brackets, two per rail, which can be welded or bolted into position.


The spreader plates slide along the rails to give the planned spacing and lock into position using the integral bolts. It is generally better to position the spreader plates facing to the rear of the implement as this can prevent wet mud or tilth being thrown up into the mouth of the spreader causing blockages, especially if positioned close behind the tractor wheels, roller or discs.

8.6 Feed Hose

The feed hose comes in 30m long coils, to be ordered as an option with a new machine. Extra rolls can be ordered as a spare part, **part no TJ222-30M**. This requires cutting into lengths according to the positioning of the hopper and spreader. Ensure all hose runs are as short as possible whilst giving a smooth downhill route to the spreader plates. Avoid kinks, severe bends or uphill runs. Plan and measure the individual hose runs before cutting, then fit the hose clips to the “Y” connector tails.




9.0 Maxi Jet Configuration



The Maxi Jet is available in a 2 or 4 outlet configuration. This refers to the number of 63mm diameter hose outlets on the air outlet manifold. Each of the outlet hoses is connected to a riser pipe with a choice of distribution heads mounted on the top. The options for the distribution heads are 6, 8, 10, 12 or 16 outlets on each riser pipe. The 6 outlet distribution head has 32mm hose tails, all the rest are 25mm. This gives a range of 12 to 64 outlets across the full range.


The images on this page show both machines with 32 outlets in different configurations. Selecting the correct option will depend on the design of the host machine, working width, folding method and accuracy required. A machine with 4 x 8 outlet distribution heads, will have increased accuracy over a 2 x 16 head machine. All the distribution heads fitted to the Maxi Jet must have the same number of outlets.




9.1 Distribution Heads

These images show all five options of different distribution heads, mounted on top of the riser pipe.


The distribution heads are secured to the riser pipe with an M8 U bolt clamp. To mount the riser pipe onto the host machine, the threads of the U bolt can be used to secure it to a bracket (not supplied).




6 outlet distribution head




8 outlet distribution head



10 outlet distribution head



12 outlet distribution head



16 outlet distribution head

10.0 Machine Components

10.1 Feed Motor

The feed motor can be turned ON or OFF, either manually via the head unit, or automatically by the remote mounted spring finger switch, which can be fitted to the linkage or the implement. The feed motor must be switched ON via the head unit for the spring finger switch to work automatically.

10.2 Hopper Agitator

The internal agitator is powered independently by a separate motor. Its purpose is to prevent seed becoming compacted in the hopper and bridging (not flowing). It is recommended for all grass and grass seed mixes, or other seed that may bridge in the hopper, but it is not required for free flowing seeds such as OSR, clover, stubble turnips or similar, or granular products.

NOTE: If using the agitator in the field, also use it when calibrating.

10.3 Hydraulic Fan Unit

The hydraulic fan unit must be mounted close enough to the tractor to allow the hydraulic hoses to reach the rear remote valves. The fan blows air to the Max Jet through a 100mm diameter ducting. Air is drawn through the mesh intakes on the sides of the fan. The fan must be mounted in a position where dust and debris ingress will be kept to a minimum. The fan is switched on and off via the tractor's hydraulic remote (spool) valves.

NOTE: The fan must not be running during calibration.

10.4 Main Power Cable

The heavy duty power cable should connect directly to the vehicle battery terminals to ensure adequate 12v supply to the Maxi Jet. The in-line MAXI FUSE is 40 amp. The battery cable should reach to the rear of the tractor. Using the Anderson plugs, this is connected to the 5m heavy duty power extension cable which connects to the power input flylead on the machine.

10.5 Instrument Lead

The 6m instrument lead connects to the junction box of the Maxi Jet, and runs to the control panel in the tractor cab.

NOTE: Extension power and instrument cables available if required.

Please contact your local Stocks Ag dealer for more information.

10.6 Spring Finger Switch

The switch should be mounted to a suitable place on the implement or linkage of the tractor, when the spring is deflected it will automatically switch the feed motor off or on as the circuit is made or broken.


Position the finger switch so that the tip of the spring comes into contact with the moving part of the Implement or linkage when lifted out of work, and remains deflected until the implement is lowered back into work.

NOTE: Ensure that there is sufficient and positive deflection on the spring to prevent accidental switching ON or OFF if the implement moves slightly up or down in work.

The standard wiring supplied for this switch, is when the spring is at rest, the feed motor will not run. The switch must be deflected to switch the feed motor on.


If required, the switch can work in the opposite mode, by changing the position of the 2 wires inside the switch so that the switch is out of work when the spring is at rest. To alter, remove the PVC cover plate held in position with the retaining screw to access the wiring terminals. Remove the 2 wires from terminals 13 and 14 and re-connect to terminals 21 and 22 (nearest the gland nut) then re-fit the PVC cover plate.

NOTE: The area meter also stops when the feed motor stops



10.7 Junction Box

The junction box is positioned on the Maxi Jet under a cover above the air inlet manifold and houses 1 toggle switch (unused with hydraulic fan) and the feed mechanism Prime Button. The switch is accessible to the side of the cover. Pushing the Prime button will start the feed motor running at a pre-set speed during calibration.



10.8 i-CON Instrument

A touch screen instrument which controls the sophisticated, CAN-based control system that provides complete control and monitoring of the applicator unit. Its primary function is to automatically maintain a pre-set target application rate as the forward speed varies, with on-the-move spot adjustment of the rate as required.




10.9 Hopper Level Sensor

A hopper level sensor is fitted as standard on i-CON machines which indicates low hopper contents.

10.10 Feed Rollers

Two types of feed roller kits are supplied with the machine as standard. The i-CON machine are fitted with the one Yellow 5mm wide small feed roller per outlet from factory with the other components making up the small seed roller kit packed in the hopper along with the larger 8 section grass seed roller kit.

Small seed rollers Fitted when applying small seeds such as oil seed rape, mustard, turnips and slug pellets. Typically 1 Yellow feed roller would be required per outlet when applying small seed and 1 or 2 White feed rollers when applying slug pellets depending upon the seed or product rate of application working width and forward speed. Up to 3 feed rollers per outlet can be fitted if required for other applications. Blanking spacers are also supplied in the kit to allow up to 3 outlets to be blanked off if required.



Outlet feed block with 3 yellow feed rollers fitted per outlet on a Maxi Jet 4

Grass seed rollers 12 of the deep 8 section feed rollers for standard application rates.

These can be altered to suit the required application rate. For a Maxi Jet 2, a minimum of 2 segments could be fitted to supply product to both of the distribution heads.

This would be a minimum of 4 segments for a Maxi Jet 4.



Outlet feed block with 3 grass seed rollers fitted per outlet on a Maxi Jet 4

11.0 Inspection


11.1 Hydraulic Fan Inspection

⚠ WARNING! Always isolate the power before inspecting or servicing the machine.

Daily inspection of the hydraulic fan is recommended. Check the hydraulic hoses between the tractor and the fan motor. Look for oil leaks and damage to the hose and fittings around the fan motor.

Check the air inlets to the fan blades, looking for build up of dust or foreign objects that could restrict air flow.

Check the 100mm ducting pipe from the fan outlet to the air inlet manifold on the Maxi Jet for cracks or loose clamps.



11.2 Feed Block Assembly Inspection

⚠ WARNING! Always observe all application standards and guidelines provided by the product manufacturer as some seed dressings and granular products may be toxic!

NOTE: If unsure contact your seed or product supplier for more information.

1. Empty the hopper completely to prevent spillage, release the two over-centre catches and drop the hinged panel under the feed rolls. Position the plastic collection tray directly underneath to catch any remaining seed or product.


2. Undo and remove the 2 black plastic knobs holding the mechanism in place and slide out the feed block assembly.

Be aware that the feed block assembly may retain some seed product.


3. Use an air line and brush to clean the feed block and internal components, checking for any wear or damage, replacing any worn or damaged parts as necessary. When doing this wear appropriate PPE.

4. Before re-fitting the feed block ensure that the feed shaft can easily be turned by hand using the Black PVC knob fitted to the end of the shaft. If it is difficult to turn, remove the end cap at the opposite end of the feed block assembly and remove all spacers and feed rollers by sliding each one off the shaft.

5. Check the drive shaft engages correctly when sliding the feed block back into the machine by slowly rotating the central black plastic knob before re-fitting the outer black plastic retaining knobs.




11.3 Agitator Shaft Inspection



Check the internal agitator shaft to ensure it is clear of any debris and free to rotate.



12.0 Hopper Emptying Procedure



The hopper drain cap can be removed to help empty the hopper. Any remaining product is best removed by using an industrial vacuum before the feed block is removed from the machine. Once the feed block has been removed from the machine dispose of any remaining product held in the feed block. Release the bottom calibration door and check the air chambers for any sign of debris or build up of product and clear as necessary.

13.0 Clearing A Feed Hose Blockage

In the unlikely event of a blockage, remove the hose and clear any obstruction from within the hose or manifold on the machine. Remove the feed block and check the air chamber below the feed block opening and clear any debris. Re-position the feed hoses if this has been the cause of the problem.

14.0 Checking The Feed Motor

⚠ WARNING! This procedure must be carried out by a competent person who is aware of any risks involved.



First empty the hopper then remove the feed block assembly.

Remove the motor guard by releasing the fixing screws.

Check to see if the feed motor shaft rotates when pressing the prime button. If the shaft is not rotating this may indicate the motor is faulty or has been damaged and needs to be replaced.

For any spare parts or if no faults are found and the alarm persists, contact your local Stocks Ag dealer.

15.0 i-CON Control System

15.1 i-CON Overview

All control system components integral to the Maxi Jet are factory fitted.


The Instrument has a 4.3" colour touch screen which has 4 basic menu keys.

Separate heavy-duty power cable and head unit leads interconnect the tractor and the Maxi Jet.

The following components need to be installed during fitment (packed in hopper from factory).

- i-CON instrument: TJ117C
- Instrument cables: TJ118C and TJ242A
- Power supply cables: TJ238 and TJ247
- GPS receiver: TJ255B
- Cut out switch: TJ252

15.2 Wiring Diagram



Ensure the power supply cable is connected directly to the vehicle battery to ensure maximum power.

Connect the positive wire (fused) to the positive (+) terminal and negative earth connection to the negative (-) terminal.

Failure to connect to the vehicle battery may result in control function problems and possible damage to the vehicle battery. The charging system must be in good condition to achieve the best results. All cables and controls are fitted with matching plugs and sockets. Extension cables available.

Any modification to the wiring, fuse holder or controls will invalidate any warranty claim and may affect the performance.

Always replace any blown fuse with the same rated fuse as the original one fitted.

15...3 i-CON Instrument Functions



1. Seed application rate (kg/ha or Seeds/m²).
2. Forward speed (km/hr).
3. Minimum/maximum forward speed indicator with alarms, (beyond which the programmed seed rate cannot be maintained).
4. Metering unit status (On/Off) and alarm.
5. Hydraulic fan speed in rpm
6. Hopper contents (kg) and low level alarm.
7. Part and full (Job) totals for area (ha), product dispensed (kg) and hours worked.
8. Grand total for area (ha), product (kg) and hours worked.

Other features include:

1. Simple and intuitive touchscreen alarm codes and diagnostic displays in the event of system malfunction.
2. Menus for forward speed / product calibration and adjustment.
3. Pre-start' - ensures seed delivery begins immediately the drill enters work (user-programmable).
4. Rate 'Nudge' - on-the-move rate adjustment in pre-set increments (user-programmable).

NOTE: A comprehensive control system user guide also supplied (packed with the i-CON instrument).

15.4 Precision Farming Software - Optional

The instrument can be unlocked to activate the precision farming program as a cost option.

This can be requested when the machine is purchased or can be added at a later date.


16.0 i-CON Calibration


You will need the supplied plastic calibration tray, and an accurate set of scales which weighs in grams.

16.1 At The Junction Box


1. Switch the fan OFF at the junction box.
2. Release the two over-centre catches and drop the hinged panel under the cassette manifold.
3. Position the collection tray directly underneath to catch the seed.
4. Place a few kilograms of seed in the hopper.

16.2 At The i-CON Instrument

1. Make sure the fan isn't running.
2. Switch the head unit ON via the left hand side push button – wait until the start-up routine has finished and displays the main "home screen"
3. Scroll through  to the Setup Menu and select the Applicator Icon.
4. Adjust the implement width accordingly - refer to the RDS manual: Set Implement Width.




5. Ensure the correct application rate is entered – select and adjust accordingly, refer to the RDS manual, Setting the Application Rate.





6. Ensure the feed roller setup is appropriate for the intended product or seed type, application rate and forward speed range for application.


7. The instrument calculates the calibration factor from the working width, target application rate, and the metered weight delivered whilst calibrating. If however, as a result of the calibration routine, you find that you cannot achieve your desired field speed, displayed in the top right corner of the screen, then re-configure the feed roll assembly and repeat the calibration procedure.

8. Prime the feed rolls with product by pressing and holding briefly the prime button on the junction box - this will ensure a higher initial calibration accuracy. Empty the contents of the tray back into the hopper.


9. For an **Auto Calibration** from the Product Setup page, touch 

10. Touch  and enter the quantity that you wish to dispense for calibration purposes. You can enter the quantity in grams if preferred. The CAL factor will however, still be calculated in kg/rev.

11. Touch on the screen page 


12. After the  key the motor runs at the calibration speed (calculated from the simulated forward speed, width, application rate and current calibration factor).


13. The dispensed weight (based on the current calibration factor) is displayed.

14. Weigh the product dispensed and then enter the measured weight, and press 



15. A new calibration factor is then re-calculated and displayed.


16. Your in-field min and max speeds will be displayed as shown opposite. If you find that you can not achieve your desired field speed, then re-configure the feed roll assembly and repeat the calibration procedure. **NOTE:** Recommended min speed 0.8kph - 1.2kph (if not see feed roller configuration).

17. Touch  to save the new factor, it is advised to repeat the calibration two more times to ensure accuracy.



16.3 Manual Calibration

1. For a **Manual Calibration** press and hold the Prime button on the junction box, the larger the quantity dispersed the higher the accuracy of the final calibration factor will be. Release the prime button once sufficient product has been dispensed, 100 to 900 grams is sufficient.
2. The estimated dispensed weight (based on the current calibration factor) is displayed.
3. Weigh the product dispensed (in grams) and then enter the measured weight, and press .
4. A new calibration factor is then re-calculated and displayed.
5. Your in field min and max speeds will be displayed. If you find that you cannot achieve your desired field speed, then re-configure the feed roll assembly and repeat the calibration procedure.
6. Touch  to save the new factor, it is advised to repeat calibration two or three more times to ensure accuracy.



16.4 GPS Speed

The i-CON control system is automatically configured to run with the GPS receiver supplied and is a simple plug and play device. This system only works outside and if you are not receiving a GPS signal an alarm will display on the main screen indicating NO GPS.

16.5 Common Calibration Mistakes

- Ensure you enter the width and required rate correctly – that the decimal point is in the correct position. If the rate is 2.5 kg/ha, enter 2.5. (not 25 - which is 25kg/ha).
- Remember to deduct the weight of the collection bag or bucket – weigh only the contents.
- Ensure you work in grams – not kilograms.
- Ensure you are working in the mode required – either Kilograms per Hectare or Seeds per Square Metre. The standard default mode for the i-CON is in Kgs/Ha and you will have to reconfigure the display if you want to display Seeds per Square Metre. You do not need to enter or change the TGW if working in Kgs/Ha – only if working in Seeds per Square Metre - Refer to the RDS manual.
- Ensure you check the minimum and maximum speeds displayed, and that they are sensible for your field operation. This is the speed range that the i-CON can maintain the required application rate, and depends on the width of your machine, the application rate required, and the type and configuration of feed rolls fitted.
- Ensure that the speed range will work for you in the field – ensure that your target forward speed will not be close to either the minimum or the maximum of the range, and that you have some reserve of speed range above and below the in-field forward speed. Ideally your forward speed will be in close to the middle of the range.
- If the minimum is too high, for example 4kph then the feed motor will be running too slowly if your forward speed drops towards the minimum as you set in and lift out of work, and this could result in missed patches (although the alarm will trigger when either the minimum or maximum speed is reached).
- If the indicated speed range does not work for your operation, you must change the feed roll configuration or the type of feed roll to apply more or less seed, per revolution of the feed mechanism, as required. Once completed, recalibrate and note the new speed range.

16.6 Ready For Work

Check the hydraulic hoses to the hydraulic fan.

Ensure the fan is running – switch junction box fan switch to ON.

Ensure the feed motor is running and agitator motor is switched on if required.

Check all outlet pipes are seeding correctly before commencing work.

17.0 Feed Block Assembly Guide

⚠ WARNING! The moving parts of this machine are powerful and can cause injury. Be especially careful whilst performing calibration tests.

⚠ WARNING! Always observe all application standards and guidelines provided by the product manufacturer as some seed dressings and granular products may be toxic.

NOTE: If unsure contact your seed or product supplier for more information.

17.1 Feed Roller Configuration



The most versatile feed roller is the 50mm diameter 8 vane. The Maxi Jet feed block can have a maximum of 12 segments fitted. For the Maxi Jet 2 this is 6 segments per outlet and the Maxi Jet 4 has 3 segments metering per outlet. By substituting segments for blanks, the number per outlet can be altered.

The Maxi Jet is capable of very high outputs, and also very low application rates. Each distribution head can have product fed to it and metered by just one segment. That product metered is then split through each of the outlets on the distribution head.

Example: One 8 vane segment over an outlet could be supplying up to 16 spreader plates.

NOTE: If you cannot achieve the required rate using just a single 8 vane flexible segment. The yellow or white segments, or multiple of segments per outlet can be used to achieve the required rate.

The choice of roller fitted will be determined by a number of factors, including product type, application rate, working width and forward speed.

WARNING! It is the responsibility of the operator to ensure the feed block assembly is suitable for the product being applied.


NOTE: Before applying very fine seeds or product please contact your local dealer or Stocks Ag directly to ensure the machine is suitable. Failure to do so could invalidate your warranty.

⚠ The feed rollers are easily exchanged by removing the feed mechanism as follows:

1. Ensure the hopper is completely empty.
2. Undo and remove the 2 black plastic knobs holding the mechanism in place and slide out the feed block.
3. Undo and remove the 4 socket head screws on the end of the housing and remove the end plate. Slide the feed rollers and spacers off the shaft and replace with the alternative rollers required.



1 segment per outlet on Maxi Jet 2



1 segment per outlet on Maxi Jet 4, or

2 segments per outlet on Maxi Jet 2

NOTE: When re-fitting the end plate to the feed block after changing the feed roller configuration. Some seeds or other products can force their way in between the feed roller segments.

In time this will cause the roller to become increasingly difficult to turn and will ultimately lead to a machine fault.

To reduce the chance of this occurring, it is important to make sure the feed rollers are tightly fitted into the feed block. When assembling, it is advised the segments are under a small amount of compression. It is acceptable for the end plates to compress a gap of 3 to 4mm when securing the end plate. To check the correct feed roller and spacer configuration, the roller should rotate within the feed block by just using two fingers and a thumb to turn. Once re-assembled, slide the feed block assembly back into the machine ensuring the drive shaft engages correctly by slowly rotating the feed shaft. Once engaged secure the two black plastic retaining knobs.

16.2 Small Seed/Granular Rollers

For some applications, such as applying very small seed or granular product, a low rate feed block assembly is recommended. This block has been developed to eliminate finer products from leaking around the feed rollers and into the airstream. These feed blocks can be used with the standard feed rollers supplied with the machine when applying very small seeds at low rates.

Small Seed Feed Block



Part Number: **47MJT5002**

Granular Feed Block



Part Number: **47TJT5021**

The possible configurations of feed rollers in the Maxi Jet differ from other pneumatic applicators, like the Turbo Jet, by only requiring one segment per distribution head, unlike a Turbo Jet that requires a segment per outlet. This means a single 8 vane grass seed segment that is usually too large for small seeds, can now be fitted to meter product to between 6 and 16 spreader plates.

In some situations, this can still give an application rate that is too high, this is where a small seed roller would be used.

The small seed block is used for low application rates, small seeds like oil seed rape (canola), clover, slug pellets etc. These segments can be supplied in the low rate precision feed block, or fitted into the standard feed block.


NOTE: Stocks Ag does not currently recommend using the Maxi Jet for Avadex application. For the application of Avadex at wider working widths, please speak to the office about the Hydraulic Turbo Jet.

Avadex ®* is a Trademark used under licence by Gowan Crop Protection Ltd.

⚠ WARNING! It is the responsibility of the operator to ensure the feed block assembly is suitable for the product being applied.

NOTE: Before applying very fine seeds or product please contact your local dealer or Stocks Ag direct to ensure the machine is suitable. Failure to do so could invalidate your warranty.

18.0 Hopper Baffle Plate



Hopper baffle plate Part number: **TJ472**

⚠ WARNING! A Hopper Baffle Plate must be fitted when applying fertiliser or any other dense product to reduce the pressure on the feed block assembly and so reduce strain on the feed motor. Failure to do so may damage the feed motor and invalidate the warranty.

NOTE: All 400L machines are supplied with a hopper baffle plate as standard.

All parts available through your local Stocks Ag dealer.



19.0 Hydraulic Fan - Specification

| Hydraulic Fan Specification | | |
|-----------------------------|------|-------|
| Model | FC4 | |
| Max RPM | 7000 | rpm |
| Max Operational RPM | 6000 | rpm |
| Max Pressure | 210 | bar |
| Max Operational Pressure | 172 | bar |
| Displacement | 4.1 | cc |
| Flow | 27.3 | L/min |
| Power | 9.54 | NM |
| Weight | 16 | kg |

19.1 Hydraulic Fan - Motor

The 4cc hydraulic fan motor on the Maxi Jet is connected to the tractors hydraulic remote (spool) valves via 3/4 hydraulic hose. The oil pressure hose connects to the side of the motor marked with IN stamped into the housing, using a 3/4 BSP adaptor. The return side is marked with an OUT stamp and connects to a T piece (see photos below). The 3/4 BSP side of the T piece is the free flow return to the tractor. The T hydraulic piece fitting, is to allow the smaller hose for the case drain, which also acts as the bypass for the motor safety protection.

| | | |
|--------------------|-------------------|-----------------------|
| Oil Feed IN | Case Drain | Oil Return OUT |
| Pressure | Bypass | Free Flow |



19.2 Hydraulic Fan - Safety

The hydraulic system on the machine operates under high pressure. (Maximum of 210 bar). Pressurised hydraulic oil is dangerous so connecting/disconnecting the fan must only be undertaken with the tractor engine turned off and the pressure in the hoses released. Before operating the machines hydraulics, always inspect the hoses and fittings to ensure there is no damage or loosened parts. If you find any damaged hoses, you must contact your dealer to have them replaced immediately.

Never try to block leaking hydraulic hose pipes with your hand or fingers! Hydraulic oil leaking out under high pressure may enter the skin and bloodstream and cause serious injuries. If injuries caused by hydraulic oil occur, immediately contact the medical services.

The tractor must be equipped with a free-return flow hydraulic connector (NO BACK PRESSURE). The oil flow necessary to drive the fan is taken from the tractors hydraulic remote valves, through a 3/4 inch delivery hose with BSP male fitting. The rotational speed of the hydraulic motor, and therefore the fan, is connected to the oil flow adjustable from the tractor's controls. The hydraulic motor safety valve makes it possible for the device to keep on turning by momentum, even after the system has been shut off. It is important to connect the return hose of the hydraulic motor to a free flow connection on the tractor; this free discharge cannot generate any back-pressure exceeding 2 bar.

Failing to follow these instructions will increase the risk of motor faults and increase the risk of premature failure of the feed mechanism.

19.3 Hydraulic Fan - Fitting Position

The hydraulic fan will drawn in large quantities of air when running. The air inlet to the fan must be kept clear of obstructions. Where possible, mount in a location that will minimise the amount of dust being drawn in, as this will impede the performance of the applicator.

The hydraulic fan is supplied with a pair of 4 metre long hoses, for pressure and return to reach from the fan motor to the remote (spool) valves on the tractor. For trailed implements, please allow some extra slack in the hoses, which will be required when making sharp turns.

The hydraulic fan is supplied with a 2 metre hose that connects the fan outlet to the air inlet manifold of the applicator.

19.4 Hydraulic Fan - Speed Setting

The hydraulic fan generates a greater volume of air flow at higher speeds than the 12v electric fans, allowing higher volumes of material to be conveyed over wider working widths.


The fan is driven by a hydraulic motor, which is powered by the tractor hydraulic system.

The hydraulic motor has a overrun protection built in.

The rpm of the fan is measured by a NPN (Negative Positive Negative) sensor with a two pulse pick up point (2ppr).


The fan speed determines the volume and speed of air used to deliver product to the outlets. The correct speed required varies depending on product size, application rate and overall working widths. Fan speed is altered by adjusting the flow control on the hydraulics of the tractor.

If the tractor is not equipped with variable flow control on the hydraulic remote (spool) valves, there is a flow control valve available as an optional extra. This valve fits on the pressure hose at the tractor end. The speed is adjusted by restricting the oil flow to the fan.



Optional flow control valve for adjusting fan speed.

Call the office for more information.



19.5 Hydraulic Fan Speed Guide

The fan speeds in the table below are just an rough guide. The correct speed required will alter greatly between varying setups depending on machine location, hose length and hose routing.

| Fan Speed rpm | 6m | 8m | 12m | 15m |
|---------------|---------------------------|---------------------------|---------------------------|---------------------------|
| 3500 | Small seeds, OSR, Clover | Small seeds, OSR, Clover | | |
| 4000 | Slug pellets, | Small seeds, OSR, Clover | | |
| 4800 | Barley, Wheat, Fertiliser | Slug pellets, | Small seeds, OSR, Clover | Small seeds, OSR, Clover |
| 5500 | Larger Seeds, Peas | Barley, Wheat, Fertiliser | Slug pellets, | Slug pellets, |
| 6000 | Larger Seeds, Peas | Larger Seeds, Peas | Barley, Wheat, Fertiliser | Barley, Wheat, Fertiliser |

19.6 Hydraulic Fan - Speed Display


With the hydraulic fan option has been purchased, the i-CON control box comes pre-configured to display the fan speed on the screen in rpm.



19.7 Hydraulic Fan - Speed Sensor


Mount the fan speed sensor in the grill over the fan inlet, using the hole provided.

Each time one of the bolt heads mounted on the fan blade passes in front of the sensor, it generates a pulse and the LED on the back flashes red.




The picture opposite shows the two bolt heads that are used as the pick up points for the fan speed sensor.

The grill over the fan inlet has to be removed to fit the sensor. The grill is held in place with four M8 bolts.



It is vital to install the fan speed sensor in the correct position. The sensor has an M12 fine thread with two nuts and lock washers to hold it in place. The blue tip to the sensor is roughly 30mm from the underside of the grill cover.

The critical measurement is the 1.5mm clearance between the sensor tip and the bolt heads. If the distance is too great, the LED will not flash. If it is too little, there is a risk of permanent damage to the sensor.




19.8 Hydraulic Fan - Mounting


To mount the hydraulic fan, the back plate is pre drilled with four M8 bolt holes.

It is recommended that all four bolt holes are used to mount the fan on a frame to support the fan securely.

The diagram below gives the dimensions for the hole locations and spacing.




20.0 Maxi Jet Parts - Control System




i-CON INSTRUMENT CONTROL PANEL


PART No: TJ117C



JUNCTION BOX i-CON MKII
PART No: TJ119D




GPS RECEIVER
PART No: TJ255B



FINGER CUT-OUT SWITCH
PART No: TJ252
MOUNTING PLATE
PART No: TJ253

20.1 Maxi Jet Parts Drawing

STOCKS 2/4 OUTLET MAXI JET C/W
HYDRAULIC FAN & 400L HOPPER
PART No's:
2 OUTLET - 47MJT0015
4 OUTLET - 47MJT0011



TYPICAL ISOMETRIC VIEW
SCALE 1 : 7

| | | | | | | | |
|----------------|----|---------------------------|----------|--|------------|--|--|
| DRAWING NUMBER | | 97APCS151 | | REVISIONS | | Stocks AG Ltd | |
| DESCRIPTION | | FINAL PRODUCTION ASSEMBLY | | Material specified -> SEE TO SALES ORDER | | GROANELL ROAD, WISBECH, CAMBRIDGESHIRE, UK Tel: 01434 (0) 1943 44 990 www.stocksag.co.uk | |
| Revising | 1 | Sheet 1 of 6 | Sheet A5 | Drawn | 10/07/2023 | Stocks AG Ltd | |
| Units | mm | Weight (kg) | 390.73 | Date | | | |

20.1 Maxi Jet Part Numbers

| Item | Part No. | Description | Qty. | Remarks |
|------|-----------------|---------------------------------|---------|-----------------|
| 1 | TJ400A | Chassis (8 outlet) | 1 | |
| | TJ400B | Chassis (10 outlet) | 1 | |
| 2 | TJ422 | Base Plate (8 & 10 outlet) | 1 | |
| 3 | TJ425A | Fan Guard (8 outlet) | 1 | |
| | TJ425B | Fan Guard (10 outlet) | 1 | |
| 4 | TJ418 | Motor Guard (8 outlet) | 1 | |
| | TJ459 | Motor Guard (10 outlet) | 1 | |
| 5 | TJ429 | Agitator Motor Plate | 1 | |
| 6 | TJ465 | Support Plate Kit | 1 | Set of 4 plates |
| 7 | TJ101A | Feed Block End Cap | 2 | Counter Bored |
| 8 | TJ102 | Feed Block (8 outlet) | 1 | |
| | TJ098C | Feed Block (10 outlet) | 1 | |
| 8a | TJ102A | Low Rate Feed Block (8 outlet) | 0 | Cost Option |
| | TJ098D | Low Rate Feed Block (10 outlet) | 0 | Cost Option |
| 9 | TJ103 | Fastener Assembly | 4 | |
| 10 | TJ104D | Metering Shaft (8 outlet) | 1 | |
| | TJ099C | Metering Shaft (10 outlet) | 1 | |
| 11 | TJ033 | Gasket | 1 | |
| 12 | TJ124C | Double Fan Unit (8 & 10 outlet) | 1 | |
| 13 | TJ126A | Hopper (240L) | 1 | |
| | TJ125A | Hopper (400L) | 1 | |
| 14 | TJ138 | Agitator Shaft (8 outlet) | 1 | |
| | TJ138A | Agitator Shaft (10 outlet) | 1 | |
| 15 | | | | |
| 16 | TJ219 | Blanking Plug (8 & 10 outlet) | 3 | |
| 17 | TJ218A | Feed Unit Manifold (8 outlet) | 1 | |
| | TJ217A | Feed Unit Manifold (10 outlet) | 1 | |
| 18 | TJ220- Assembly | "Y" Connector—Assembly | 8 or 10 | 8 or 10 outlet |
| | | | | |
| 20 | TJ222 | Ø32mm Hose | 30m | Not shown |
| 21 | TJ223 | Clamp Assembly | | |
| 22 | TJ224 | Spreader Plate (Assembly) | | 8 or 10 outlet |
| 23 | TJ227 | Ø40mm BZP Hose Clip | | 8 or 10 outlet |
| 24 | TJ038 | Strip Seal | 2.4m | |
| 25 | TJ021A | Agitator Paddle (8 outlet) | 4 | |
| | TJ021A | Agitator Paddle (10 outlet) | 5 | |

20.2 Maxi Jet Part Numbers Continued

| Item | Part No. | Description | Qty. | Remarks |
|------|----------|----------------------------|------|---------|
| 26 | TJ137 | Coupler | 1 | |
| 27 | TJ131 | 4mm Allen Key | 1 | |
| 29 | TJ416 | Cassette Mounting Plate | 1 | |
| 31 | TJ128 | Hopper Lid | 1 | |
| 32 | TJ129 | Neck Ring | 1 | |
| 33 | TJ130 | PVC Calibration Tray | 1 | |
| 34 | FJ033A | M8 Fem Knob | 3 | |
| 35 | GRO03 | Rubber Grommet | 2 | |
| 36 | TJ053 | Rubber Washer | 1 | |
| 37 | TJ054 | Rubber Washer | 1 | |
| 39 | GA046B | Agitator Motor | 1 | |
| 41 | TJ040 | Feed Block Gasket | 1 | |
| 42 | TJ041 | Junction Box Gasket | 1 | |
| 44 | GA103 | PVC Flanged Bush | 6 | |
| 45 | TJ055-1 | PVC Plug | 1 | |
| 47 | TJ430 | Hinge Guard (8 outlet) | 1 | |
| | TJ431 | Hinge Guard (10 outlet) | 1 | |
| 48 | TJ044B | Feed Motor | 1 | |
| 49 | TJ039 | Rubber Grommet | 1 | |
| 50 | TJ043A | Coupler | 1 | |
| 51 | M10-004 | M10x25 Bolt | 3 | |
| 52 | FJ419A | R' Clip | 4 | |
| 53 | M6-003 | M6 Setscrew | 2 | |
| 54 | M6-016 | M6 Flat Washer | 2 | |
| 55 | M5-011 | M5 Setscrew | 4 | |
| 56 | M5-014 | M5 Flat Washer | 4 | |
| 57 | M6-004 | M6x16 Bolt | 2 | |
| 58 | M6-004 | M6x16 Bolt | 3 | |
| 59 | M6-007 | M6x20 CSK Setscrew | 4 | |
| 60 | M6-016 | M6 Flat Washer | 6 | |
| 61 | M6-008 | M6x25 Button Head Setscrew | 4 | |
| 62 | M8-004 | M8x20 Dome SQ Bolt | 16 | |
| 63 | M8-010 | M8 Flat Washer | 16 | |
| 64 | M8-012 | M8 Penny Washer | 2 | |
| 65 | M10-001 | M10x16 Bolt | a/r | |
| 66 | M4-004 | M4 Lock Nut | 4 | |
| 67 | M10-016 | M10 Flat Washer | a/r | |
| 68 | M10-024 | M10 Lock Nut | 3 | |
| 69 | M12-003 | M12x35 Bolt | 4 | |


20.3 Maxi Jet Part Numbers Continued

| Item | Part No. | Description | Qty. | Remarks |
|------|----------|--|------|------------------|
| 70 | M12-008 | M12 Flat Washer | 8 | |
| 71 | M12-014 | M12 Lock Nut | 4 | |
| 72 | M4-001 | M4x6 Socket Head Setscrew | 8 | |
| 73 | M4-006 | M4 Flat Washer | 8 | |
| 74 | M8-019 | M8 Lock Nut | 16 | |
| 75 | TJ150 | 'C' Rail 2 metre length | 4 | |
| 76 | TJ151A | Channel Nut | a/r | |
| 77 | TJ152-1 | Short Clamp Plate 2 Holes | a/r | |
| 78 | TJ153 | Long Clamp Plate 3 Holes | a/r | |
| 79 | TJ050 | Tank Outlet | 1 | |
| 80 | TJ051 | Nut | 1 | |
| 81 | TJ052 | Blanking Cap | 1 | |
| 82 | TJ251A | i-CON Hopper Level Sensor | 1 | |
| | | | | |
| 83 | M4-006 | M4 Flat Washer | 8 | |
| 84 | M4-003 | M4 Setscrew | 8 | |
| 85 | | | | |
| 86 | TJ1285 | Self Tapping Screw | 2 | |
| 87 | M5-015 | Washer | | |
| 88 | MM019 | Loop Link Chain | 1 | |
| 89 | TJ471 | Tank Baffle (8 outlet) | 1 | 400L models only |
| | TJ472 | Tank Baffle (10 outlet) | 1 | 400L models only |
| 90 | TJ196A | 8 Outlet Feed Block Assembly | 1 | |
| | TJ196E | 10 Outlet Feed Block Assembly | 1 | |
| | TJ196B | 8 Outlet Low Rate Feed Block Assembly | 1 | Cost Option |
| | TJ196F | 10 Outlet Low Rate Feed Block Assembly | 1 | Cost Option |
| 93 | TJ435A | Door Release Shaft TJ8 | 1 | |
| | TJ440A | Door Release Shaft TJ10 | | |
| 94 | TJ437A | Door Release Catch Plate | 1 | |
| 95 | TJ433 | E-clip | 1 | |
| 100 | M3-003 | M3 Bolt | 1 | |
| 101 | M3-008 | M3 Lock Nut | 1 | |
| 102 | TJ117C | i-CON Instrument Control Panel | 1 | |
| | | | | |
| | | | | |
| 103 | TJ118C | i-CON Instrument Connector Cable | 1 | Not shown |
| 104 | TJ119D | i-CON Junction Box | 1 | |
| 107 | TJ252 | Finger Cut Out Switch | 1 | |
| 108 | TJ254 | 6m Switch Cable | 1 | Not shown |
| 109 | TJ235 | Instrument Mounting Bracket | 1 | Not shown |

StocksAG


21.1 High Capacity Feed Roller Parts

| ITEM NO | PART NO | Description | Qty |
|---------|-----------|--|-----|
| 1 | 97APC5196 | 59mm DIAMETER- 6 VANE -28.0 WIDE FEED ROLLER | 12 |
| 2 | 97APC5299 | SHIM WASHER 59mm DIAMETER | 11 |
| 3 | FJ033A | M8 FEMALE PLASTIC KNOB - BLACK | 1 |
| 4 | GA103 | FLANGED PVC BUSH | 2 |
| 5 | M6-006 | M6 x 20 HEX SOCKET BUTTON HEAD SET SCREW ST/ST | 4 |
| 6 | M6-007 | M6 x 20 CSK SOCKET HEAD SET SCREW ST/ST | 4 |
| 7 | M6-016 | M6 FLAT WASHER FORM A ST/ST | 4 |
| 8 | MJ098-2 | FEED BLOCK BODY | 1 |
| 9 | TJ033 | WASHER GASKET | 1 |
| 10 | TJ099D | SQUARE SHAFT | 1 |
| 11 | TJ101A | FEED END BLOCK PLATE | 2 |
| 12 | TJ416 | CASSETTE MOUNTING PLATE | 1 |




21.2 Standard Feed Roller Parts - Full Set

| ITEM No | PART NUMBER | DESCRIPTION | QTY |
|---------|-------------|--|-----|
| 1 | FJ032A | M8 FEMALE PLASTIC KNOB - BLACK | 1 |
| 2 | GA103 | FLANGED PVC BUSH | 2 |
| 3 | GA1108-A | 8 SECTION FEED ROLLER 28mm WIDE | 6 |
| 4 | GA1108-B | 8 SECTION FEED ROLLER 28mm WIDE | 6 |
| 5 | MA-007 | M6 x 20 CSK SOCKET HEAD SET SCREW ST/ST | 4 |
| 6 | MA-008 | M6 x 25 HEX SOCKET BUTTON HEAD SET SCREW ST/ST | 4 |
| 7 | MD-016 | M6 FLAT WASHER FORM A ST/ST | 4 |
| 8 | MD021 | ROTATION ARROW DECAL | 1 |
| 9 | MD098 | FEED BLOCK BODY - 50mm | 1 |
| 10 | TJ033 | WASHER GASKET | 1 |
| 11 | TJ09D | SQUARE SHAFT | 1 |
| 12 | TJ101A | FEED END BLOCK PLATE | 1 |
| 13 | TJ214 | 5.3mm WIDE BLANKING SPACER | 2 |
| 14 | TJ416 | CASSETTE MOUNTING PLATE | 1 |




21.3 Standard Feed Roller Parts - 4 Segments

| ITEM NO | PART NUMBER | DESCRIPTION | QTY |
|---------|-------------|--|-----|
| 1 | FJ033A | M8 FEMALE PLASTIC KNOB - BLACK | 1 |
| 2 | GA103 | FLANGED PVC BUSH | 2 |
| 3 | GA110B-A | 8 SECTION FEED ROLLER 28mm WIDE | 4 |
| 4 | GA114 | BLANKING SPACER 24.0 WIDE | 6 |
| 5 | M6-007 | M6 x 20 CSK SOCKET HEAD SET SCREW ST/ST | 4 |
| 6 | M6-008 | M6 x 25 HEX SOCKET BUTTON HEAD SET SCREW ST/ST | 4 |
| 7 | M6-016 | M6 FLAT WASHER FORM A ST/ST | 4 |
| 8 | MD021 | ROTATION ARROW DECAL | 1 |
| 9 | MD098 | FEED BLOCK BODY - 50mm | 1 |
| 10 | TJ083 | WASHER GASKET | 1 |
| 11 | TJ099D | SQUARE SHAFT | 1 |
| 12 | TJ101A | FEED END BLOCK PLATE | 2 |
| 13 | TJ207A | 3mm WIDE BLANKING SPACER | 2 |
| 14 | TJ213 | 39.5mm WIDE BLANKING SPACER | 2 |
| 15 | TJ416 | CASSETTE MOUNTING PLATE | 1 |




21.4 Standard Feed Roller Parts - 2 Segments

| ITEM No | PART NUMBER | DESCRIPTION | QTY |
|---------|-------------|--|-----|
| 1 | FL032A | M8 FEMALE PLASTIC KNIB - BLACK | 1 |
| 2 | GA103 | FLANGED PVC BUSH | 2 |
| 3 | GA110B-A | 8 SECTION FEED ROLLER 28mm WIDE | 2 |
| 4 | GA114 | BLANKING SPACER 24.0 WIDE | 9 |
| 5 | MA-007 | M6 x 20 CSK SOCKET HEAD SET SCREW 5/16" | 4 |
| 6 | MA-008 | M6 x 25 HEX SOCKET BUTTON HEAD SET SCREW 5/16" | 4 |
| 7 | MA-016 | M6 FLAT WASHER FORM A 5/16" | 4 |
| 8 | MD021 | ROTATION ARROW DECAL | 1 |
| 9 | MD098 | FEED BLOCK BODY - 50mm | 1 |
| 10 | TJ033 | WASHER GASKET | 1 |
| 11 | TJ099D | SQUARE SHAFT | 1 |
| 12 | TJ101A | FEED END BLOCK PLATE | 2 |
| 13 | TJ209 | 15.4mm WIDE BLANKING SPACER | 4 |
| 14 | TJ416 | CASSETTE MOUNTING PLATE | 1 |




21.5 Small Seed Feed Roller - Parts

| ITEM NO | PART NUMBER | DESCRIPTION | QTY |
|---------|-------------|--|-----|
| 1 | 97APCS198 | PRECISION 4 OUTLET 50.8mm DIAMETER FEED BLOCK | 1 |
| 2 | FJ033A | M8 FEMALE PLASTIC KNOB - BLACK | 1 |
| 3 | GA103 | FLANGED PVC BUSH | 2 |
| 4 | M6-007 | M6 x 20 CSK SOCKET HEAD SET SCREW ST/ST | 4 |
| 5 | M6-008 | M6 x 25 HEX SOCKET BUTTON HEAD SET SCREW ST/ST | 4 |
| 6 | M6-016 | M6 FLAT WASHER FORM A ST/ST | 4 |
| 7 | MD021 | ROTATION ARROW DECAL | 1 |
| 8 | TJ033 | WASHER GASKET | 1 |
| 9 | TJ099D | SQUARE SHAFT | 1 |
| 10 | TJ101A | FEED END BLOCK PLATE | 2 |
| 11 | TJ199 | STAINLESS STEEL SHIM WASHER | 24 |
| 12 | TJ201 | 5mm WIDE LOW RATE FEED ROLLER - YELLOW | 12 |
| 13 | TJ203 | 24.6mm WIDE MID SPACER - WHITE | 3 |
| 14 | TJ204 | 13mm WIDE BLANKING SPACER | 1 |
| 15 | TJ205 | 5mm WIDE BLANKING SPACER | 12 |
| 16 | TJ207A | 3mm WIDE BLANKING SPACER | 2 |
| 17 | TJ208 | 10mm WIDE BLANKING SPACER | 8 |
| 18 | TJ210 | 18.0 WIDE SPACER - WHITE | 2 |
| 19 | TJ416 | CASSETTE MOUNTING PLATE | 1 |



22.0 Hydraulic Fan - Parts (Diagram)



22.1 Hydraulic Fan - Parts List

| Item | Part Number: | Description | Qty |
|------|--------------|-------------------------------|-----|
| 1 | 97APC5452 | CRARY HYDRAULIC FAN | 1 |
| 2 | 97APC5454 | HYDRAULIC FAN HOSE KIT (Pair) | 1 |
| 3 | 97APC5456 | 4 INCH PVC DUCTING | 1 |

Notes

[illegible]